

7/31/15 10:27 AM

IMPORTANT SAFETY INFORMATION

Explanation of Attention Words and Symbols used in this guide



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION, used without the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in harm to your dog.

AWARNING

- Not for use with aggressive dogs. Do not use this product if your dog is aggressive, or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or a certified trainer.
- This device contains Lithium-Ion (Li-Ion) batteries; never incinerate, puncture, deform, short-circuit, or charge with an inappropriate charger. Fire, explosion, property damage, or bodily harm may occur if this warning is not followed.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.
- Batteries should never be removed from the battery compartment for charging.
- Risk of explosion if batteries are charged in areas with high temperature (100° F+ / 38° C+).

CAUTION Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long, or made too tight on the dog's neck may cause skin damage. This is called bed sores; it is also called decubitus ulcers or pressure necrosis.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible, reposition the collar on the dog's neck every 1 to 2 hours.
- Check the fit to prevent excessive pressure: follow the instructions in this manual.
- Never connect a lead/leash to the electronic collar: it will cause excessive pressure on the contacts.
- When using a separate collar for a lead/leash, don't put pressure on the electronic collar.
- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Examine the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.

For additional information on bed sores and pressure necrosis, please visit the Support section for remote trainers at www.sportdog.com.

These steps will help keep your dog safe and comfortable. Millions of dogs are comfortable while they wear stainless steel contacts. Some dogs are sensitive to contact pressure. You may find after some time that your dog is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed.

- You may need to trim the hair in the area of the Contact Points or switch to the longer Contact Points to ensure consistent contact. Never shave the dog's neck; this may lead to a rash or infection.
- You should not make the collar any tighter than is required for good contact. A collar that is too tight will increase the risk of pressure necrosis in the contact area.
- Unauthorized changes or modifications to the equipment may violate FCC regulations and could void the user's authority to operate the equipment.

۲

Thank you for choosing SportDOG Brand® training products. Used properly, this product will help you train your dog efficiently and safely. To ensure your satisfaction, please review this owner's manual thoroughly. If you have questions regarding this product's operation, please contact our Customer Care Center at 1-800-732-0144, visit our website at www.sportdog.com, or view our support videos at www.youtube.com/sportdogbrand.

To get the most protection out of your One Year Warranty, please register your product within 30 days at www.sportdog.com. By registering, and keeping your receipt you will enjoy the product's full warranty and should you ever need to call the Customer Care Center, we will be able to help you faster. Most importantly, your valuable information will never be given or sold to anyone. Complete warranty information is available online at www.sportdog.com/support/warranty.

TABLE OF CONTENTS

PREPARE THE COLLAR RECEIVER*	5
FIT THE COLLAR RECEIVER*	8
FIND THE BEST INTENSITY LEVEL FOR YOUR DOG	
CHANGING STATIC STIMULATION RANGES*	11
PROGRAM THE REMOTE TRANSMITTER*	
MATCH THE COLLAR RECEIVER AND REMOTE TRANSMITTER*	14
PROGRAM THE SYSTEM FOR TWO OR THREE-DOG OPERATION*	14
CHANGE ID CODES*	
TERMS OF USE AND LIMITATION OF LIABILITY	
FCC COMPLIANCE	
BATTERY DISPOSAL	
SPORTDOG™ ADD-A-DOG® RECEIVERS	20

* You Tube videos available at www.youtube.com/sportdogbrand

TEP :: 01

 (\mathbf{h})

PREPARE THE COLLAR RECEIVER

CHARGE THE COLLAR RECEIVER

- 1. Lift the rubber cover protecting the Charging Jack.
- 2. Connect one of the charger connectors to the Charging Jack.
- 3. Plug the charger into a standard 120/240-volt AC wall outlet.
- Charge the Collar Receiver for 2 hours for the first charge and every charge thereafter.

Using Li-lon technology, the Collar Receiver only requires a 2 hour charge. It is not harmful to let the unit charge for more than 2 hours.

TO TURN THE COLLAR RECEIVER ON

Press and release the On/Off Button. The Collar Receiver Indicator Light will come on and the Collar Receiver will beep 1 - 2 times on a SDR-AF or 2-3 times on a SDR-AS/SDR-AC depending on what stimulation range is chosen. The default is 2 (medium) on a SDR-AF and 3 (high) on a SDR-AS/SDR-AC.



CHARGER CONNECTOR PLACED IN THE COLLAR RECEIVER CHARGING JACK

ON/OFF BUTTON

TO TURN THE COLLAR RECEIVER OFF

Press and release the On/Off Button. The Receiver Indicator Light comes on solid (red) and the Collar Receiver beeps continuously for 2 seconds.

To extend the life between charging cycles, turn the Collar Receiver off when it is not in use.

NOTE: Approximate battery life between charges is 50 to 70 hours, depending on frequency of use.

4

 $(\mathbf{0})$

 \bigcirc

RECEIVER INDICATOR LIGHT

OPERATIONAL MODE	LIGHT Color	BATTERY STATUS	LIGHT FUNCTION	SPEAKER FUNCTION	VIBRATION
Unit is turned on via On/Off Button	Green	Good	Light is solid in color during beep sequence	Beeps 1-2 times on SDR-AF, or 2-3 times on SDR-AS/	N/A
Unit is turned on via On/Off Button	Red	Low	Light is solid in color during beep sequence	SDR-AC depending on stimulation range setting (2 is the default setting for SDR-AF; 3 is the default setting for SDR-AS/SDR-AC). Please see page 11.	
Unit is turned off via On/Off Button	Red	N/A	Light is solid in color during beep sequence	Beeps continuously for 2 seconds	N/A
Unit is on	Green	Good	Light flashes every 2 seconds	N/A	N/A
Unit is on	Red	Low	Light flashes every 2 seconds	N/A	N/A
Unit is delivering continuous static stimulation	Red	N/A	Light is solid in color for as long as button is pressed (up to 10 seconds)	N/A	N/A
Unit is delivering momentary static stimulation	Red	N/A	Light will quickly flash once no matter how long button is pressed	N/A	N/A
Unit is delivering tone stimulation	Off	N/A	N/A	Unit will beep for as long as button is pressed	N/A
Unit is delivering vibration stimulation	Off	N/A	N/A	N/A	Unit will vibrate for as long as button is pressed (up to 10 seconds)
Unit is charging	Green	Low	Light is solid in color while connected to charger	N/A	N/A
Unit is fully charged (charger still connected)	Green	Good	Light flashes once per second once the battery is completely charged	N/A	N/A

1-800-732-0144

RECHARGEABLE BATTERIES

▲WARNING

۲

- This device contains Lithium-Ion (Li-Ion) batteries; never incinerate, puncture, deform, short-circuit, or charge with an inappropriate charger. Fire, explosion, property damage, or bodily harm may occur if this warning is not followed.
- Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions (see page 18).
- · Batteries should never be removed from the battery compartment for charging.
- Risk of explosion if batteries are charged in areas with high temperature (100° F+ / 38° C+).
- The rechargeable Lithium Ion (Li-Ion) batteries are not memory sensitive, do not require depletion before charging, and cannot be over charged.
- The batteries come partially charged from the factory, but will require a full charge before the first use.
- When storing the unit for long periods, remember to regularly give batteries a full charge. This should be done once every 3 to 4 months.
- You should expect hundreds of recharge cycles from your batteries. However, all rechargeable batteries lose capacity over time relative to the number of recharge cycles they experience. This is normal. If your operating time drops to half of the original life, contact the Customer Care Center to purchase a new battery.
- The batteries should last for a period of 3-5 years. When a battery needs replacement, you can order a new
 pack by calling our Customer Care Center at 1-800-732-0144. Please do not open the Collar Receiver until you
 have received the replacement.

6

 $(\mathbf{1})$

STEP :: 02

FIT THE COLLAR RECEIVER

IMPORTANT: The proper fit and placement of the Collar Receiver is important for effective training. The Contact Points must have direct contact with your dog's skin.

CAUTION

Please read and follow the instructions in this manual. Proper fit of the collar is important. A collar worn for too long, or made too tight on the dog's neck may cause skin damage. This is called bed sores; it is also called decubitus ulcers or pressure necrosis.

- Avoid leaving the collar on the dog for more than 12 hours per day.
- When possible reposition the collar on the dog's neck every 1 to 2 hours.
 Check the fit to prevent excessive pressure; follow the instructions in this manual.
 Never connect a lead/leash to the electronic collar; it will cause excessive pressure on the contacts.


• When using a separate collar for a lead/leash, don't put pressure on the electronic collar.

- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Examine the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue use of the collar until the skin has healed.
- If the condition persists beyond 48 hours, see your veterinarian.

For additional information on bed sores and pressure necrosis, please visit the Support section for remote trainers at www.sportdog.com.

These steps will help keep your dog safe and comfortable. Millions of dogs are comfortable while they wear stainless steel contacts. Some dogs are sensitive to contact pressure. You may find after some time that your dog is very tolerant of the collar. If so, you may relax some of these precautions. It is important to continue daily checks of the contact area. If redness or sores are found, discontinue use until the skin has fully healed.

 With your dog standing (2A), center the Collar Receiver so the Contact Points are underneath your dog's neck, touching the skin (2B). If your dog has a long or thick coat, you have




two options to ensure consistent contact: either trim the hair around the Contact Points or switch to the longer Contact Points included with your system.

CAUTION

(b)

- You may need to trim the hair in the area of the Contact Points. Never shave the dog's neck; this may lead to a rash or infection.
- You should not make the collar any tighter than is required for good contact. A collar that is too tight will increase the risk of pressure necrosis in the contact area.
- The Collar Receiver should fit snugly, yet loose enough to allow one finger to fit between the strap and your dog's neck (2C).
- 3. Allow your dog to wear the collar for several minutes, and then recheck the fit. Check the fit again as your dog becomes more comfortable wearing the Collar Receiver.



8

 $(\mathbf{0})$

FIND THE BEST INTENSITY LEVEL FOR YOUR DOG

Your SportDOG Brand® remote training system has multiple intensity levels. This allows you to choose the static stimulation level that is best for your dog.

NOTE: Always start at the lowest level and work your way up.

For training efficiency, it is important to find the right intensity level for your dog. This is called the Recognition Level, at which your dog looks around in curiosity or flicks his ears.

FINDING YOUR DOG'S RECOGNITION LEVEL:

NOTE: Every dog is different and you cannot predict where your dog's Recognition Level will be. Watch closely for any slight change in behavior that demonstrates your dog is feeling the static stimulation.

- With the Collar Receiver turned on and properly fitted to your dog, set the Remote Transmitter's Intensity Dial at Level 1 and press the Continuous Static Stimulation Button for 1 to 2 seconds.
- 2. If your dog shows no reaction to Level 1, go to Level 2 and repeat the process.
- YOUR DOG SHOULD NOT VOCALIZE OR PANIC WHEN RECEIVING STATIC STIMULATION. IF THIS HAPPENS, THE STATIC STIMULATION LEVEL IS TOO HIGH AND YOU NEED TO GO BACK TO THE PREVIOUS LEVEL AND REPEAT THE PROCESS.
- Once you find your dog's Recognition Level, this is the level you should use when you begin a training exercise.
- 5. If you have progressed to Level 7 while searching for your dog's Recognition Level and your dog continues to show no response, check to see if the Collar Receiver is snug against your dog's neck. Then go back to Intensity Level 1 and repeat the process. If your dog still does not indicate he is feeling the static stimulation, you have three options: trim the hair beneath the Contact Points, switch to the longer Contact Points included in your system, or change to a higher static stimulation range.

If after completing all of these steps your dog still does not indicate he is feeling the static stimulation, please contact the Customer Care Center at 1-800-732-0144.

CHANGING STATIC STIMULATION RANGES

Your SDR-AF, SDR-AS, or SDR-AC Collar Receivers come with 2 stimulation ranges (**low and medium for the SDR-AF**; **medium and high for the SDR-AS/SDR-AC**). There are 7 stimulation levels within each range, with 1 being the lowest and 7 being the highest. The default range setting is 2 (medium) for the SDR-AF and 3 (high) for the SDR-AS/SDR-AC.

To change the range of stimulation, follow these steps:

- 1. Make sure the Collar Receiver is off.
- 2. Then turn the unit on by pressing and releasing the On/Off Button.
- 3. After the Indicator Light turns off and within 5 seconds, press and hold the On/Off Button for 3 seconds.
- 4. The Collar Receiver will then beep once and the Indicator Light will flash orange. This indicates Low stimulation range. If Medium or High are desired, continue to hold the On/Off Button until the number of beeps/orange flashes equals the desired stimulation range shown in the chart below.
- 5. Release the On/Off Button once the desired range is selected; the Collar Receiver will turn off.
- 6. Turn the unit back on. It will then beep according to the stimulation range selected in Step 4.

	STATIC STIMULATION RANGE	DOG TEMPERAMENT
1 beep (SDR-AF only)	Low	Mild
2 beeps	Medium	Moderate
3 beeps (SDR-AS/SDR-AC only)	High	Stubborn

 (\mathbf{A})



PROGRAM THE REMOTE TRANSMITTER

The Remote Transmitter has seven operational modes to allow you to select the best match for your type or style of training. The Remote Transmitter is factory set to mode 1. There is also one programming mode: Mode V/T (Change ID Codes) on page 15.

TO CHANGE THE MODE:

 Referring to the following table, adjust the Intensity Dial to your desired mode.
 Turn the Remote Transmitter over.

3. Using a pen or the tine on the buckle of your collar strap, press and release the Mode Button. When the Mode Button is pressed, the Transmitter Indicator Light will be solid in color. When it is released, it will flash the number of times for the mode selected.



۲

For example, if mode 4 is desired, adjust the Intensity Dial to Level 4. Once the Mode Button has been depressed, the Transmitter Indicator Light will be solid and, once the mode button is released, the Transmitter Indicator Light will flash 4 times.

MODE	UPPER BUTTON Function	LOWER BUTTON Function	SIDE BUTTON Function	NUMBER OF DOGS
1*	Continuous stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Momentary stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Tone only	1
2	Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Momentary stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Vibe only	1
3	Dog 1 : Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Dog 2 : Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Dog 3 : Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	3
4	Dog 1 : Continuous stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Dog 2 : Continuous stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Dog 3 : Continuous stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	3
5	Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Momentary stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Remote Launcher	1
6	Continuous stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Momentary stimulation (Level set by intensity dial) OR Vibe if V/T on Dial	Remote Launcher	1
7	Continuous stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Momentary stimulation (Level set by intensity dial) OR Tone if V/T on Dial	Locate Remote Beeper**	1
V/T (ID CODE)	N/A	N/A	(See STEP 7)	N/A

* Factory Default Mode

۲

** Locate Remote Beeper: The Side Button turns run mode off and locates the Remote Beeper. To enable run mode again, press and hold the Side Button for 3 seconds.

۲

12

7/31/15 10:27 AM



MATCH THE COLLAR RECEIVER AND REMOTE TRANSMITTER

To match the Collar Receiver to work with a new Remote Transmitter or to match a new Collar Receiver to work with your existing Remote Transmitter:

- A. Turn the Collar Receiver off.
- B. Press and hold the On/Off Button. The Receiver Indicator Light will come on, then turn off after 4-5 seconds. If the On/Off Button is released too early, the Receiver Indicator Light will begin flashing as normal. If this occurs, start over from A.
- C. After the Receiver Indicator Light has turned off, release the On/Off Button.
- D. Press and hold the Upper Button on the Remote Transmitter until the Receiver Indicator Light flashes 5 times. Once the Receiver Indicator Light has flashed 5 times, the Collar Receiver has been matched and will begin flashing as normal. If the Receiver Indicator Light does not flash 5 times, start over from A.



PROGRAM THE SYSTEM FOR TWO OR THREE-DOG OPERATION

SportDOG[™] Add-A-Dog[®] Collar Receiver(s) must be purchased to train additional dogs.

- 1. Program the Remote Transmitter to mode 3 or 4 (see page 13).
- 2. Program the first Collar Receiver.
 - A. Turn the Collar Receiver off.
 - B. Press and hold the On/Off Button. The Receiver Indicator Light will come on, then turn off after 4-5 seconds. If the On/Off Button is released too early, the Receiver Indicator Light will begin its normal flashing. If this occurs, start over from A.
- C. After the Receiver Indicator Light has turned off, release the On/Off Button.
- D. Press and hold the **Upper Button** on the Remote Transmitter until the Receiver Indicator Light flashes 5 times. If the Receiver Indicator Light does not flash 5 times, start over from **A**.
- 3. Program the second Collar Receiver using **A** through **D** above, but using the **Lower Button** in place of the Upper Button.
- 4. Program the third Collar Receiver using **A** through **D** above, but using the **Side Button** in place of the Upper Button.

CHANGE ID CODES

•

П

(b)

An ID Code is the signal identification between the Remote Transmitter and Collar Receiver. Each is programmed in 1 of 2,000 ID Codes from the factory. The FieldTrainer® 425/425S and WetlandHunter® 425 have the flexibility to program two or more Remote Transmitters to the same ID Code, allowing them to both control one Collar Receiver. There are 64 programmable ID Codes available.

TO MANUALLY PROGRAM A REMOTE TRANSMITTER'S ID CODE FOLLOW THESE STEPS:

- Turn the Intensity Dial to V/T, and then press and release the Mode Button on the back of your Remote Transmitter. This does not change the mode, so the current mode will still be active after the ID change is complete.
- Once the Mode Button is released, the Transmitter Indicator Light will illuminate solid green and stay on for 15 seconds.
- While the green Indicator Light is on, turn the Intensity Dial to select the 1st digit of the ID and then press and release the Side Button. The green Indicator Light will flash rapidly confirming selection.
- 4. Again, while the green Indicator Light is on, turn the Intensity Dial to select the 2nd digit of the ID and then press and release the Side Button. The green Indicator Light will flash rapidly confirming selection. The 2nd digit is optional and, if not desired, wait until the green light turns off and refrain from pressing the Side Button.
- 5. At the end of 15 seconds, or after the second press of the Side Button, the green Indicator Light will turn off and the ID of the unit will be updated. At this point, the unit will be in the same mode it was in prior to setting the ID.
- Upon changing the ID Code, you will need to match the Collar Receiver to the Remote Transmitter (see STEP 5 on page 14).

TO RETURN THE UNIT TO THE FACTORY ID FOLLOW THESE STEPS:

- Turn the Intensity Dial to V/T, and then press and release the Mode Button on the back of your Remote Transmitter. This does not change the mode, so the current mode will still be active after the ID change is complete.
- 2. Do not press any buttons and wait until the green Transmitter Indicator Light turns off.
- 3. You will need to match the Collar Receiver to the Remote Transmitter (see STEP 5 on page 14).

TERMS OF USE AND LIMITATION OF LIABILITY

1. TERMS OF USE

This Product is offered to you conditioned upon your acceptance without modification of the terms, conditions, and notices contained herein. Usage of this Product implies acceptance of all such terms, conditions, and notices.

2. PROPER USE

This Product is designed for use with dogs where training is desired. The specific temperament of your dog may not work with this Product. We recommend that you not use this Product if your dog is less than 8 pounds or if your dog is aggressive. If you are unsure whether this is appropriate for your dog, please consult your veterinarian, certified trainer, or contact our Customer Care Center at 1-800-732-0144.

Proper use includes reviewing the entire Operating Guide provided with your Product and any specific safety infromation..

3. NO UNLAWFUL OR PROHIBITED USE

This Product is designed for use with dogs only. This dog training device is not intended to harm, injure, or provoke. Using this Product in a way that is not intended could result in violation of Federal, State, or local laws.

4. LIMITATION OF LIABILITY

In no event shall Radio Systems Corporation be liable for any direct, indirect, punitive, incidental, special or consequential damages, or any damages whatsoever arising out of or connected with the use or misuse of this Product. Buyer assumes all risks and liability from the use of this Product.

5. MODIFICATION OF TERMS AND CONDITIONS

Radio Systems Corporation reserves the right to change the terms, conditions, and notices under which this Product is offered.

FCC COMPLIANCE

(

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If interference does occur to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and the receiver.
- · Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- · Contact customer service or an experienced radio/TV technician for assistance.

CAUTION

Unauthorized changes or modifications to the equipment may violate FCC regulations and could void the user's authority to operate the equipment.

IC - CANADA

This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes : (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Customer Care Center / Service clientèle

800-732-0144

働

Monday - Friday / Lundi - Vendredi 8 am - 8 pm EST / 8h00 - 20h00 EST Saturday / Samedi 9 am - 5 pm EST / 9h00 - 17h00 EST

()

()

🕱 BATTERY DISPOSAL

AWARNING See Important Safety Information related to the battery on page 2.

This system operates on one Li-lon battery pack (160mAh capacity for the Collar Receiver). Only replace with battery received from calling the Customer Care Center at 1-800-732-0144.

(())

働

Separate collection of spent batteries is required in many regions; check the regulations in your area before discarding spent batteries. Please see below for instructions on how to remove the battery from the product for separate disposal. If you wish to ship us your spent batteries for disposal, contact the Customer Care Center.

AT END OF PRODUCT LIFE, USE THESE BATTERY REMOVAL INSTRUCTIONS FOR FINAL DISPOSAL (DO NOT OPEN THE COLLAR RECEIVER UNTIL YOU HAVE RECEIVED THE REPLACEMENT):

- Using a 3/32 Allen wrench remove the case screws.
- Remove the case back or cover.
- · Remove the old battery pack.

AWARNING

()

- When removing the old battery pack, care must be taken when gripping the connector firmly to avoid damaging the
 wires. Shorting the battery wires may cause fire or explosion.
- These instructions are not valid for repair or battery replacement. Replacing the battery with a battery not specifically
 approved by Radio Systems Corporation may cause fire or explosion. Please call the Customer Care Center at
 1-800-732-0144 to avoid invalidating your warranty.

This product is protected by the following patents: U.S. Patent Numbers: 7,420,136; 7,647,545; 6,184,790; 6,459,378 Canada Patent Number: 2,565,318



REALTREE MAX-5 Camouflage Pattern ©2013 of Jordan Outdoor Enterprises, Ltd., all rights reserved.



GEAR THE WAY YOU'D DESIGN IT®

©2014, 2015 RADIO SYSTEMS CORPORATION Radio Systems Corporation • 10427 PetSafe Way • Knoxville, TN 37932 • 1-800-732-0144 400-1594/2

DO NOT PRINT THIS PAGE

Radio Systems [®] C O R P O RA T I O N The world leader in pet training products	RSC Part #: 400-1594 Description: SDR-AF/SDR-AS/SDR-AC Manual Created by: AR
Material: Cover:128g C2S; Body:100g Wood free paper Color: White Printing: Cover: CMYK X 1C body: 1C x 1C Coating: Cover with Aqueous Varnish; Cut, fold 2 times, 2 saddle stitch, and Bulk Pack	Initial Creation Date: 8/24/2012 Approved by: GG
	Date Approved: 8/28/2012 Program used: INDESIGN CC
	Revision: 002 ECO: RSC12091
	Revision Description:Max-5 Update Revision Date: 7/28/2015